

Notes and update instructions

Due to constant technical progress, we keep our products up to date with ongoing software development. We therefore recommend that you check your system for new software before configuring it personally to ensure the best possible functionality. Adjustments to the software may also change the operation of the user interface via notebook and smartphone.

You can download the software update and a current operating manual from our homepage "www.megasat.tv/support/downloads" or under the respective product. The update can be carried out in two different ways on the "WEB-UI interface" of the device. Choose the best option for you.

In the following video, we show you two ways to update your system with the latest software. www.megasat.tv/wp-content/uploads/megasat_connected_wifi_booster_update_english.mp4



Download-Link



Video-Link

Option 1:

- Download the new software from the Megasat.tv homepage.
- Unzip the software into a folder of your choice.
- Make sure that your device is connected to the WLAN of the indoor router.
- Open the WebUI for your indoor router with 192.168.1.1 (see also operating instructions)
- Scroll to the bottom of the page and select the Outdoor field. This will also connect you to the outdoor unit 192.168.2.66 and log in.
- Select the option "System" / "Firmware" / "Update firmware"
- Switch off the "Keep settings" option and click on Browse.
- Now open the folder in which you saved the update and select the file (EAP7****) for the outdoor unit and click on Open. The file is now loaded and checked.
- If the check is successful, press the "Continue" button. The outdoor unit is now updated.
- Then switch to the indoor receiver (192.168.1.1) and carry out the same steps until the file selection. Select the file (CMR7****) for the indoor unit and start the update.

The update takes approx. 3-5 minutes and the devices then restart. Now you can configure your system according to your personal wishes.

Option 2: (device must be connected to the Internet)

- Make sure that your device is connected to the WLAN of the indoor router.
- Open the WebUI for your indoor router with 192.168.1.1 (see also operating instructions)
- Select the option "System" / "Maintenance" / "CLI"
- Enter the following to log in: **root** ; Password: **admin**
- In the following command line, please enter the following: **wget http://megasat.tv/ota** press Enter and then the command: **sh ota** and confirm with Enter.
- The devices are now automatically updated with the latest update from our homepage and are then ready for use again.

The update takes approx. 3-5 minutes and the devices then restart. Now you can configure your system according to your personal wishes.



manual-link

Important: Do not disconnect the power supply until the update is complete.

Note:

By registering your Megasat product at "www.megasat.tv/support/produktregistrierung", you will automatically be notified by e-mail when new firmware is available for your product.

You will also always find the latest operating instructions for your device on our homepage.